



Installation

Model specific instructions

For:

- Royal Enfield Himalayan

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in the front left hand side of the air filter box.
- It is a bit tight around the AIT sensor so you need slim fingers to reach the AIT sensor connector, but it is definitely possible to install the BoosterPlug without dismantling the bike completely.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head. Next to the air-box snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- Royal Enfield Himalayan

